



2015-16 Colorado/ Canyon 4", 5", and 6" 2WD Lift Kit

Thank you for choosing Rough Country for all of your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read all the instructions before beginning the installation. Check the kit hardware against the Kit Contents list on next page. Be sure you have all the needed parts and understand where they go. Also please review the tools needed list to be certain that you have the tools necessary to complete the installation.

PRODUCT USE INFORMATION

▲ WARNING As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend, because of roll-over possibility, that seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side roll-over may occur. Braking performance and capabilities are decreased when significantly larger/heavier tires and wheels are used. Take this into consideration while driving. Also, speedometer recalibration is necessary when larger tires are installed.

Do not add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, with this suspension lift voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

▲ NOTICE Due to differences in manufacturing, dimension and inflated measurements, tire and wheel combinations should be test fit prior to installation. A quality tire of radial design is recommended. **Factory wheels will not fit.**

For the **4"** lift application we recommend an 18" wheel not to exceed 9" in width with **5" of backspacing/ 0 offset** and a **275/65-18** tire.

For the **5"** lift application we recommend an 18" wheel not to exceed 9" in width with **5" of backspacing/ 0 offset** and a **275/65-18** tire.

For the **6"** lift application we recommend an 18" wheel not to exceed 9" in width with **5" of backspacing/ 0 offset** and a **285/65-18** tire.


▲ NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product must have the "Warning to Driver" decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. **INSTALLING DEALER**—It is your responsibility to install the warning decal and to forward these installation instructions on to the vehicle owner for review and to be kept in the vehicle for its service life.


We hope installing your Rough Country lift kit is a positive experience. Please note that variations in construction and assembly in the vehicle manufacturing process will virtually ensure that some parts may seem difficult to install. Additionally, the current trend in manufacturing of vehicles results in a frame that is highly flexible and may shift slightly on disassembly prior to installation. The use of pry bars and tapered punches for alignment is considered normal and usually does not indicate a faulty product. However, if you are uncertain about some aspect of the installation process, please feel free to call our tech support department at 800-222-7023. We do not recommend that you modify the Rough Country parts in any way as this will void any warranty expressed or implied.



KIT CONTENTS



6" KIT PICTURED



Kit Contents: For 4" Lift 221.20

1241Box3:

- Front Crossmember (A)
- Rear Crossmember (B)
- 1221BAG1

1221Box2:

- Lower Skid Plate (C)
- 1221BAG5

1221Box3:

- Front Skid Plate (D)

1221Box4:

- Dr & Pass. Knuckles (E)

1221Box5 : (4in Lift Box)

- 2.5in Blocks (2) (F)
- U-bolts (4) (G)
- 658695 Shocks (2) (H)
- Strut Extensions (2) (I)
- 1221BAG4
- Strut Bushings (4)
- Sleeves (4)

1252Box1:

- Strut Clamp (4) (L)
- Sway Bar Links (2) (M)
- Front Brake Line Relocation (2) (N)
- Rear Brake Line Relocation (O)
- Rear E-Brake Relocation (P)
- 1252BAG6
- 1252BAG4

Boxes Below are in place of 1221Box5:

1233Box1: (5in Lift Box)

- 3.5in Blocks (2)
- U-bolts (4)
- 658698 Shocks (2)
- Strut Extensions (2)
- 1221BAG4
- Strut Bushings (2)
- Sleeves (4)

1241Box1: (6in Lift Box)

- 4.5in Blocks (2)
- U-bolts (4)
- 658708 Shocks (2)
- Strut Extensions (2)
- 1221BAG4
- Strut Bushings (2)
- Sleeves (4)

Fastener Breakdown:

For Front Cross Member: 1221Bag1

- 5/8" x 4.5" Bolt (2)
- 5/8" Nylock Nut (2)
- Flat Washer (4)

For Rear Cross Member:

- 5/8" x 4" Bolt (2)
- 5/8" Nylock Nut (2)
- Flat Washer (4)

For Strut Extension: 1221Bag4

- 3/8" x 1 1/4" Bolt (8)
- 3/8" Flange Lock Nut (8)

For Strut Clamp: 1221Bag4

- 7/16" x 3 1/4" Bolt (4)
- 7/16" Top Lock Nut (4)

For ABS Line on Knuckle: 1252BAG6

- 1/4" x 1" Bolt (2)
- 1/4" Flat Washer (4)
- 1/4" Nylock Nut (2)

For Skid Plates: 1221Bag5

- 3/8" x 1 1/4" Bolt (7)
- 3/8" Flat Washer (7)

For Front Brake Line Brkt: 1252BAG6

- 1/4" x 1" Bolt (4)
- 1/4" Nylock Nut (4)

- 1/4" Flat Washers (8)

For Rear Brake Line Brkt: 1252BAG6

- 5/16" x 1" Bolt (1)
- 5/16" Flat Washer (1)

- 5/16" Flange Lock Nut (1)

For Rear E-Brake Bracket: 1252BAG6

- 5/16" x 1" Bolt (1)

- 5/16" Flat Washer (1)

- 5/16" Flange Lock Nut (1)

For Rear Shocks: 1221Bag4

- Shock Sleeves (4)

Rear U-bolts: 9/16Bag

- 9/16" Nylock Nuts (8)

- 9/16" Flat Washers (8)

TORQUE SPECS:

Size	Grade 5	Grade 8
3/8"	30 ft/lbs	35 ft/lbs
7/16"	45 ft/lbs	60 ft/lbs
1/2"	65 ft/lbs	90 ft/lbs
9/16"	95 ft/lbs	130 ft/lbs
5/8"	135 ft/lbs	175 ft/lbs
	Class 8.8	Class 10.9
10MM	32ft/lbs	45ft/lbs
12MM	55ft/lbs	75ft/lbs
18MM	170ft/lbs	240ft/lbs


TOOLS NEEDED:

- 6mm Allen
- 10mm socket /wrench
- 13mm socket /wrench
- 15mm socket / wrench
- 16mm wrench
- 17mm socket / wrench
- 18mm socket /wrench
- 21mm socket /wrench
- 24mm socket /wrench
- 35mm socket
- T30
- Torque Wrench
- 7/16 socket/wrench
- 1/2 socket/ wrench
- 5/8 socket/ wrench
- 9/16 socket /wrench
- 11/16 socket/ wrench
- 13/16 socket/ wrench
- 15/16 socket/ wrench
- Loc-Tite
- Reciprocating Saw
- Floor Jack
- Jack Stands
- Pliers




INSTALLATION INSTRUCTIONS


1. Chock the rear wheels.
2. Jack up the front of the vehicle.
3. Place jack stands on the frame behind the lower control arms.
4. Lower the vehicle onto the jack stands and remove the tires and wheels.
5. Place the floor jack under the differential.
6. Using a 15mm socket remove the factory skid plate. Retain factory hardware. **See Photo 1.**
7. Using 15mm socket, remove the differential skid. **See Photo 2.**



8. Unplug the connectors going to the electric power steering. **See Photo 3.**
9. Remove tie-rod using a 21mm socket / wrench. Using a hammer strike the knuckle to break the taper loose. Retain the stock hardware. **See Photo 4.** You may have to hold the TRE with a 10mm wrench when loosening.





10. Using a 18mm socket remove the brake caliper from the factory knuckle. **Do Not allow caliper to hang from brake line.** Retain the factory hardware. **See Photo 5.**
11. Using a T30 remove the brake rotor from the hub assembly. **See photo 6.**





12. Using a T30, remove the ABS sensor from the knuckle. **Photo 7.**

13. Using a 10mm socket, remove the ABS line from the back of the knuckle. **See Photo 8.**




14. Using a 18mm wrench, loosen the upper ball joint nut, **Do Not remove at this time.** Strike the knuckle with a hammer to break the taper loose. **See Photo 9.** You may need to use a 6mm Allen to hold the ball joint.

15. Using a 24mm wrench, loosen the lower ball joint nut, **Do Not remove at this time.** Strike the knuckle with a hammer to break the taper loose. Remove the upper and lower ball joint nuts and remove the knuckle. **See Photo 10.**



16. Using a 13mm socket and 15mm wrench, remove sway bar links. Retain bushings for reuse. **See Photo 11.** Sway bar may need to be removed to allow easier removal of the strut.



17. Using a 21mm socket, remove the lower strut bolt. Retain for reuse. **See Photo 12.**
18. Using 18mm wrench, remove the upper strut nuts. Retain for reuse. Remove the strut from the vehicle. **See Photo 13.**



Photo 12

Remove lower strut bolt from lower control arm.




Photo 13

Remove strut.

19. Using 24mm wrenches, remove the lower control arm bolts and cam washers. Retain for reuse. **See Photo 14.**
20. Remove lower control arm from vehicle. **See Photo 15.**



Photo 14

Remove cam bolts and washers.




Photo 15

Remove lower control arms.

21. Remove the 4 bolts (2 each side) securing the cross-member using a 18mm socket and wrench. **See Photo 16.**
22. Remove the rear cross member from the vehicle. **See Photo 17.**




Photo 16

Remove rear crossmember bolts (4).








Photo 17

Remove rear crossmember.

23. Measure 1" down from the lower control arm alignment adjustment slot and mark. Repeat this process on both sides of the front control arm pockets. **See Photo 18.**
24. Connect measurement marks from both sides of the control arm pocket as shown in **Photo 19.** Trim this line using a



- reciprocating saw.
25. Reinstall the lower control arm with stock hardware. **See Photo 20. Do not tighten at this time.**
26. Using 15/16" socket and wrench tighten the front and rear cross member mounting bolts. **See Photo 21.**



27. Press the stock bushings out of the struts. **See Photo 22.**
28. Install the supplied aluminum bushings, from 1221BAG4 (1221BOX5, 1233BOX1, or 1241BOX1), in the lower strut eyelet. **See Photo 23.**



29. Install the strut clamp on the bottom of the strut using 3/8" x 1.25" bolts and hardware in 1221BAG4 (1221BOX5, 1233BOX1, or 1241BOX1) **See Photo 24.**
30. Slide the strut extension onto the bottom of the strut. **See Photo 25.**
31. Place (2) of the 7/16" x 3.25" bolts and top lock nuts from 1221BAG4 (1221BOX5, 1233BOX1, or 1241BOX1) through the lower mounts of the strut and strut clamp. Tighten using 5/8" socket and 11/16" wrench. **See Photo 25.**
Make sure nut will be facing away from CV boot when installed on the truck.



Photo 24

Install strut clamp.




Photo 25

Install strut extension.

32. Tighten the 3/8" clamp bolts using 9/16" socket and wrench. **See Photo 26.**
33. Lay the factory knuckle hub side down. **See Photo 27.**

▲ NOTICE Torque to 15-17ft-lbs in a X pattern.




Photo 26

Torque strut extension bolts.




Photo 27

Remove hub bolts from knuckle.

34. Using a 13mm socket remove the 4 hub bolts from the factory knuckle. **See Photo 28.**
35. Place new lift knuckle on hub bearing and tighten hub bolts using a 13mm socket. **See Photo 29.**



Photo 28


Remove hub from stock knuckle.




Photo 29

Install stock hub in lifted knuckle.

36. Install strut assembly onto vehicle using factory hardware. Tighten the upper nuts with a 18mm wrench. **See Photo 30. Do not tighten lower strut bolt at this time.**
37. Install lifted knuckle on ball joints with stock hardware. Tighten using a 18mm for the upper and 24mm for the lower. **See Photo 31.**




Install strut assembly.



Install knuckle.

38. Install ABS sensor in the knuckle and tighten using T30. **See Photo 32.**
39. Measure 1" from the edge of the bottom of the dust shield. **See Photo 33.**



Install ABS sensor into knuckle.




Mark brake dust shield.

40. Mark a line as shown in **Photo 34**, and cut dust shield with a reciprocating saw. Grind sharp edges and paint to prevent rusting.
41. Install brake rotor and tighten using a T30.
42. Install brake caliper onto knuckle using factory hardware. Tighten using a 18mm socket. **See Photo 35.**





Cut brake dust shield for caliper clearance.




Install brake caliper.



43. Attach ABS wire to the knuckle using supplied 1/4" x 1" bolts and hardware from 1252BAG6 (1252BOX1). **See Photo 36.**
44. Install the front brake line relocation bracket using the 1/4" x 1" bolt and hardware from 1252BAG6 (1252BOX1). Tighten using 7/16" wrenches. **See Photo 37.**




45. Install the new sway bar links, ball stud end up, using supplied hardware. Tighten the top using a 21mm socket and a 9/16" wrench to keep from spinning. Tighten the bottom using a 15mm socket and a 13mm wrench to keep from spinning. **See Photo 38.**
46. Reinstall the tie rod and tighten using a 21mm wrench. **See Photo 39.**



47. Reconnect electric rack and pinion wiring. **See Photo 40.**
48. Install upper and lower skid plates using the (7) 3/8" x 1.25" bolts and hardware from 1221BAG5 (1221BOX2). Attach the upper skid plate to the frame using factory hardware. Tighten using 9/16" and 15mm sockets. **See Photo 41.**





49. Install wheel and tires and lower the vehicle to the ground.
50. Tighten the lower strut bolt using a 21mm socket.
51. Tighten the lower control arm adjusting bolts using a 24mm wrench and socket. **See Photo 42.**




REAR INSTALLATION INSTRUCTIONS



1. Chock the front tires.
2. Position a floor jack under the rear differential and jack up the vehicle.
3. Place jack stands under the frame rails just forward of the front leaf spring hangers and lower the frame on the jack stands.
4. Reposition the floor jack under the center of the differential and apply slight pressure for support, but do not raise the frame off the jack stands.
5. Using a 13mm wrench, remove the E-brake and brake line brackets from the frame.
6. Remove the rear shock with a 21mm wrench on the upper and lower mount **See Photo 1**.




7. Using a 21mm remove the u-bolts and lower u-bolt plate. **See Photo 2**.
8. Place supplied lift block between the leaf spring and axle pad. **Thicker end of the block goes to the rear of the truck. See Photo 3.** The 4" kit utilizes a 2.5" block, the 5" kit a 3.5" block and the 6" kit a 4.5" rear block.





9. Install supplied u-bolts over the leaf spring. Use the factory lower u-bolt plate. **See Photo 4**.
10. Secure using the supplied hardware from 9/16BAG (1221BOX5, 1233BOX1, or 1241BOX1). Tighten using 13/16" wrench. **See Photo 5**.
11. Attach the supplied rear brake line relocation bracket to the frame using the factory hardware. Attach the factory brake line bracket to the relocation bracket using the 5/16" x 1" bolt and hardware from 1252BAG6 (1252BOX1). Tighten using 1/2" wrenches. **See Photo 6**.



12. Attach the supplied rear E-brake relocation bracket to the frame using the factory hardware. Attach the factory E-brake bracket to the relocation bracket using the 5/16" x 1" bolt and hardware from 1252BAG6 (1252BOX1). Tighten using 1/2" wrenches. **See Photo 7.**
13. Using rubbing alcohol as a lubricant, place the (4) supplied sleeves into shock eyelets. The 4" kit uses shock number **658695**. The 5" kit uses shock number **658698** and the 6" kit uses shock number **658708**.
14. Using the factory hardware, place the upper eyelet of the shock into the upper mount. **See Photo 8.**



15. Using the factory hardware, place the lower eyelet of the shock into the lower mount. **See Photo 9.**
16. Tighten the shock mounts using 21mm socket and wrench. **See Photo 10.**



17. Install wheels and tires and lower the vehicle to the ground.
18. Tighten lug nuts to factory specifications.

POST INSTALLATION INSTRUCTIONS

1. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Verify clearance between exhaust and brake lines, fuel lines, fuel tank, floor boards and wiring harness. Check steering gear for clearance. Test and inspect brake system.
2. On some vehicles the front lower skirting will need to be trimmed if using certain wheel /tire combinations and with heavy offset wheels. Trim only as needed.
3. Activate four wheel drive system and check front hubs for engagement.
4. Have a qualified alignment center align the vehicle immediately. Realign to factory specifications. Have headlights adjusted to proper settings.
6. Perform head light check and adjustment to proper settings.
7. Check and retighten wheels at 50 miles and again at 500 miles.
8. Recheck lifted height and adjust torsion bar as necessary.
9. All kit components must be retightened at 500 miles and then every three thousand miles after installation. Periodically check all hardware for tightness.
10. Install "Warning to Driver" decal on sun visor.

Alignment Specs

Front			
Total Toe	-0.10°	+0.10°	+0.30°
Front Camber	-0.90°	-0.10°	+0.70°
Caster	+1.80°	+2.80°	+3.80°
King-Pin	_____	_____	_____
Incl. Angle	_____	_____	_____
Rear			
Total Toe	°	°	°
Rear Camber	°	°	°
Thrust Angle	-.025°	+0.00°	+0.25°

Thank you for choosing Rough Country for all of your suspension needs.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

