




advanced FLOW engineering™
 P.O. Box 1719
 Corona, CA 92878
 Support: 951-493-7100
aFepower.com

Intercooler Tube Installation Instructions: 01-05 GM Duramax Intercooler Tube Upgrade V8-6.6L (td) LB7/LLY

Kit Part Number: 46-20048			Tools Required: 7/16" deep socket & Ratchet 3/16" hex key Teflon pipe sealant tape		Parts list 1 Tube, Upgrade - 05-60046 1 Silicone coupler reducer - 05-60047 1 T-bolt clamp, spring loaded 3.25" - 03-50530 2 Plugs, hex head socket (1/8" NPT) - 03-50029	
Make Chevrolet						
Model:	Year:	Engine:				
Silverado HD	'01-'04	V8-6.6L (td) LB7				
Silverado HD	'04.5-'05	V8-6.6L (td) LLY				
Make GMC						
Model:	Year:	Engine:				
Sierra HD	'01-'04	V8-6.6L (td) LB7				
Sierra HD	'04.5-'05	V8-6.6L (td) LLY				



Complete Stock Intercooler tube.
 (Note: the air intake system has been removed)




With 7/16" deep socket, loosen clamp on manifold.



With 7/16" deep socket, loosen clamp on intercooler coupler. Push down on intercooler tube and disconnect from manifold. Remove stock intercooler tube from vehicle.



Install plugs in to 1/8" NPT ports with 3/16" hex key. Use teflon pipe sealant tape for leak tight fit.



Install reducer coupler with clamp provided to new tube.



Install new tube and position into coupler on intercooler. Tighten and torque all clamps to 75 in-lbs.. Reinstall the air intake system and your intercooler tube installation is now complete. Thank you for choosing aFe power!

Place the included CARB EO sticker on or near the Intercooler Tube on a smooth, clean surface. EO identification label is required to pass the Smog Check Inspection.