



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369 www.consolevault.com

2022+ — Chevy Silverado, GMC Sierra 1500, 2500, 3500 Instruction Sheet (1117)



Installation Steps:

- 1) Review all steps before initiating installation.
- 2) If applicable, reset the combination lock before beginning installation.
- 3) Remove all contents from the center console, including the pad at the bottom. **Image 3-A and 3-B**
- 4) Using a 10mm socket, remove the (2) OEM screws from the bottom of the console. Save the OEM screws.
- 5) Pull each plastic bracket by hand from the left and right sides of the console bin.
- 6) Lower the safe into the vehicle console. (**Note: You may have to move the safe side-to-side to slide it past the bracket mounts.**) **Image 6**
- 7) Replace the (2) OEM screws through the mounting holes in the bottom of the Console Vault. Once finger tight, use a 10mm socket to fully tighten.
- 8) Place the Console Vault® foam pad in the bottom of the in-vehicle safe.
- 9) OPTIONAL: Replace the plastic brackets by setting the brackets into position and snapping into the mounting points.
- 10) The installation is complete! **Image 10**

