

Installation Steps:

1. Review all steps before initiating installation.
2. If applicable, reset the combination lock before beginning installation.
3. Looking at the safe, notice two pre-drilled holes located on each side of the unit (**see figure 1**).
4. With the door in the open position, carefully slide in the safe body with the lock and door facing towards the front of the vehicle console.
5. With the safe door open, take the four (4) Tek-Screws that came with your kit and finger tighten them into each fitting. Using a socket wrench, turn each screw until fully seated: **STOP! DO NOT OVERTIGHTEN!** The screws are designed to cut their own hole while turning: over tightening will cause damage to the fitting.
6. Repeat step 5 for the three (3) remaining mounting holes.
7. Installation is now complete!



Fig. 1



Fig. 2

Combination Lock Reset Guides:

Installation Steps:

IMPORTANT: Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock
User Guide](#)