

Installation Steps:

1. **ATTENTION!** Review all steps before initiating installation.
2. If applicable, reset the combination lock before beginning installation.
3. Remove all contents from the center console, only leaving the **OE** pad at the bottom.
4. With the door in the open position, carefully lower the safe into the console in the correct orientation with the lock positioned at the front.
5. Insert the **2 Self Drilling Screws** by hand, and use a **1/2" Socket Wrench** to complete tightening until the screw heads fully contact the insert nuts and **STOP!** Overtightening the screws will cause damage to the threads.
6. If a foam pad was provided with your safe, insert into the safe positioned for best fit.
7. The installation is now complete.



Combination Lock Reset Guides:

Installation Steps:

IMPORTANT: Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock
User Guide](#)