

(800) 878-1369 | www.consolevault.com

Instruction Sheet
Product SKU: 1120
Compatible Vehicle Application(s):
Chevy Tahoe/Suburban 2021+

GMC Yukon/XL/Denali 2021+

Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- Remove all contents from the center console and open the door on the Console Vault safe.
- 3) Using a 10mm socket wrench, unfasten the two (2) OEM screws from the bottom of the inside of the console. Set aside for later. (1)
- 4) Remove the pad from inside the safe. Set aside for later.
- 5) Using two hands, gently slide the safe into the console. (2)
- 6) Insert the two (2) OEM screws through the mounting holes in the bottom of the safe. Hand start the screws, then use a 10mm socket wrench to fully tighten. (3)
- 7) Place the pad inside the safe. (4)
- 8) The installation is now complete!











(800) 878-1369 | www.consolevault.com

Combination Lock Reset Guides:

Installation Steps:

IMPORTANT: Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



→ 4 Digit Lock User Guide



⇒ 3 Digit Lock User Guide



Elite 4-Digit Lock

<u>User Guide</u>