

Installation Steps:

1. Remove all contents from your vehicle's factory center console. Notice at the upper front and back of the console there are hangers that hold the tray that sits on top of the console vessel. These two hangers need removed.
2. Take the Safe lid assembly and place into position (see figures 1, 2 & 3). Once the lid assembly is in position, hold in place.
3. Take the passenger side upright and place it into position (see figure 4). Now, take two of the nuts that came with your kit and mount them upright to the lid assembly.
4. Repeat step 3 for the driver's side upright.
5. Take the "X" bracket and place into position at the bottom of the uprights (see figure 5).
6. Using the acorn nuts included with your kit, mount the "X" bracket to the uprights. When doing this, make sure that the uprights are fully pushed against the side walls of the console.
7. After the uprights and the "X" bracket are fully tightened, take the four "self-cutting" bolts and thread them into each of the "nut-serts" in the side walls of the uprights (see figure 6). Hand thread these bolts into place until they bottom-out against the plastic side wall of the factory console. Using a socket wrench, tighten these bolts. The bolts will cut their own holes.
8. Your installation is complete. You may place the console floor liner back in the base.



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5



Fig. 6

Combination Lock Reset Guides:

Installation Steps:

IMPORTANT: Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock
User Guide](#)