

Model# 1043 2011-2021 Dodge Durango 2011-2021 Jeep Grand Cherokee Installation Instructions

- 1) Remove all contents from your factory console. Looking at figure 1, gently lift up the panel covering the front portion of the console. Next slip the vault down into the factory console
- 2) Next take the "trim ring" and place it into position on top of the vault. This will be a tight/snug fit, it is designed this way to prevent any gaps. Once the trim ring is in position secure it in place using the Allen screw provided and tighten using the allen wrench. (See fig 2)
- 3) Next, looking at figure 3, take the two self cutting mounting screws and thread them into place. Only finger tighten at this time. Once you have both screws in place use a socket to start turning the screws. For best results, alternate between each screw, give one a couple of turns then repeat on the other. Continue until both screws are secure. DO NOT OVER TIGHTEN.
- 4) Finally, reinstall the panel from step one. Put the carpet liner in place and you are finished.



Figure 1



Figure 2



Figure 3