



Fig. 1



Fig. 2

- 1) If you have a combination lock reset your combination before you start the install.
- 2) Remove all the contents from your center console, including the pad at the bottom.
- 3) Slip the vault down into the console, make sure it is fully down.
- 4) On the inside of the vault notice the two threaded fittings on each side. Take the "Tek-Screws" that came with the kit and finger tighten them into each fitting. See Figure 1
- 5) Using a socket wrench tighten each screw, these screws are designed to cut their own hole while turning. DO NOT OVER TIGHTEN, just snug. See Figure 2
- 6) Put the rubber pad in the bottom of the vault.

consolevault.com | 800-878-1369