



TM

- 1) If you have a combination lock, reset your combination before you start the installation.
- 2) Remove all your contents from the center console, including the pad at the bottom.
- 3) Notice the four mounting screws in the base of your factory console, remove the two rear mounting bolts and place aside.
- 4) Slip the vault down into the console, this will be a tight fit. It may be necessary to gently push the factory console lid back a little in order for the vault to slip past.
- 5) Mount the vault using the two replacement screws that came with the kit.
- 6) Place the rubber pad in the base of the vault.

[consolevault.com](http://consolevault.com) | 800-878-1369