



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369 www.consolevault.com

2019+ — Chevy Silverado, GMC Sierra 1500, 2500, 3500 Instruction Sheet (1094)



Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- 2) Remove all contents from the center console, including the pad at the bottom.
- 3) Using a 10mm socket, remove the (2) OEM screws from the bottom of the console. Save the OEM screws.
- 4) Using a T20 Torx head screwdriver, remove the (4) screws from the file folder brackets (Figure 4A) and remove the brackets (Figure 4B).

Step 3



Step 4A



Step 4B



Step 5A



Step 5B



- 5) Slide the Console Vault into the vehicle console. **(Note: You may have to move the safe side-to-side to slide it past the folder bracket mounts.)**
- 6) Replace the (2) OEM screws through the mounting holes in the bottom of the Console Vault. Once finger tight, use a 10mm socket to fully tighten.
- 7) Place the Console Vault foam pad in the bottom of the in-vehicle safe.
- 8) OPTIONAL: Replace the folder brackets by setting the brackets into position. Tighten the (4) screws using a T20 Torx head screwdriver.
- 9) The installation is complete!

Step 6



Step 7



Step 8

