



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369 www.consolevault.com

2018+ — Jeep Wrangler JL Instruction Sheet (1092)



Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- 2) Remove all contents from the center console, including the pad at the bottom.
- 3) Place the hinged plate in the bottom of the console. **(Note: Make sure the notch on the bottom of the hinged plate is facing the front of the vehicle.)**

Step 3



Step 4



Step 5A



Step 5B



- 4) With the lid closed, put the lid assembly into the opening of the console, diagonally and with the front side facing down as shown.
- 5) Slowly bring the front edge of the lid assembly up, rotating the back right corner down into place as shown in steps 5A and 5B.
- 6) Pull the lid assembly up flat and open the lid to gain access to the hinged plate as shown in steps 6A and 6B.

Step 6A



Step 6B



Step 7



Step 8A



Step 8B



- 7) Reach inside the open lid and fold the hinged plate sides up. **(Note: There are clearance slots that will pass over (4) threaded studs.)**
- 8) Once the hinged plate sides are up, thread the (4) locknuts over the threaded studs (Figure 8A) and tighten using a 1/2" socket wrench (Figure 8B).
- 9) Hand start the (2) self-drilling screws (Figure 9A & 9B) then tighten with a 7/16" socket wrench until they come to a hard stop (Figure 9C). **(Warning! Do not over tighten, as this may cause damage to the threaded features on the safe.)**

Step 9A



Step 9B



Step 9C

