

Installation Steps:

1. Remove all contents from the center console, including OEM pad at the bottom.
2. Slide the Console Vault in-vehicle safe into the center console (2). Once in place, unlock and open the lid.
3. Hand start the (4X) self-drilling screws (3A) then tighten with a 7/16" socket wrench until they come to a hard stop (3B). (**WARNING! Do not over tighten, as this may cause damage to the threaded features on the safe.**)
4. Insert pad into in-vehicle safe (4).
5. The installation is now complete!



Step 2



Step 3A



Step 3B



Step 4



Combination Lock Reset Guides:

Installation Steps:

IMPORTANT: Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock
User Guide](#)