



## Installation Steps:

- 1) Before you start the installation reset your combination.
- 2) Remove all your contents from the storage compartment located under your front middle seat. Next take your Console Vault and slip it into this compartment. Open the lid of your Console Vault. Notice the two threaded fittings located on each side of the vault.
- 3) Now take the four self cutting screws that came with the kit and thread each screw into these fittings. Now using a socket or wrench start turning these screws. These screws are designed to cut their own hole as they turn. For best results you will want to alternate turning these screws. Give each one a couple of turns then repeat on each screw until they are fully into the fitting.  
***VERY IMPORTANT!!!! NO NOT OVER TIGHTEN THESE SCREWS, ONCE THE SCREW IS FULLY DOWN STOP. OVER TIGHTENING WILL CAUSE DAMAGE TO THE FITTING.***
- 4) Next put the OEM console liner in the bottom of the console and the installation is complete.



Fig. 1



# Combination Lock Reset Guides:

## Installation Steps:

**IMPORTANT:** Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock  
User Guide](#)