

Hidden Hinge Design (U.S. Patent Pending)

Installation Steps:

- 1) Working from the driver seat, remove all contents from the center console including the felt liner at the bottom.
- 2) Notice three OE console bolts at the bottom of the console, remove and retain them in the case that the Safe is removed.
- 3) If applicable, reset the lock combination.
- 4) Place the folding frame assembly into the bottom of the console, with the two laterally folding arms towards the front of the vehicle. Note: The slots in the folding frame will line up with the OE console nuts where the bolts were previously removed. **A1**
- 5) Place the 3 bolts included in the hardware kit through the slots and into the OE console. Tighten them but **Do not** torque them down, the folding frame should still be able to slide under the bolts.
- 6) With the Safe lid closed and the lock towards the front of the vehicle, lower the lid assembly down into the console.
- 7) Open the Safe door and align the slots on the folding frame arms with the studs on the Safe lid. **A2**
- 8) Place the three provided flange nuts on the Safe studs and fully tighten them down (**shown in red**). **A2**
- 9) Using a wrench tighten all three of the provided bolts hand tight or to 9Nm if a torque wrench is available.
- 10) Place the provided foam pad in the bottom of the Safe, lining up the cutouts with the folding frame arms.
- 11) The installation is now complete.

