

Installation Steps:



- 1) Reset the combination lock before beginning the installation.
- 2) Remove all the contents from the center console, including pad at bottom.
- 3) Slip In-Vehicle Safe down into the center console.
- 4) Open lid of the safe and notice four threaded fittings, two on the driver's side and two on the passenger side.
- 5) Next take the four Self-Drilling Screws from the hardware kit and finger them into each fitting.
- 6) Tighten each of the Self-Drilling Screws using a socket wrench, **DO NOT OVER TIGHTEN**, these screws are designed to cut their own hole while turning. Once the screw is fully seated, **STOP**.
Over tightening will damage the fitting.
- 7) Place the pad in the bottom of the safe, installation is complete.



Combination Lock Reset Guides:

Installation Steps:

IMPORTANT: Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock
User Guide](#)