

## Installation Steps:



1. If applicable, reset the combination lock before beginning installation.
2. Remove all contents from the center console, including OEM pad at the bottom.
3. Slide the Console Vault in-vehicle safe into the center console (3A). Once in place, unlock and open the lid (3B).
4. Hand start the (2) self-drilling screws (4A) then tighten with a 7/16" socket wrench until they come to a hard stop (4B). (**Warning! Do not over tighten, as this may cause damage to the threaded features on the safe.**)
5. Insert the Console Vault 1099 bin mat (5A and 5B).
6. The installation is now complete!

Step 2



Step 3A



Step 3B



Step 4A



Step 4B



Step 5A



Step 5B



Step 6



# Combination Lock Reset Guides:

## Installation Steps:

**IMPORTANT:** Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock  
User Guide](#)