

## Installation Steps:



- 1) Remove any contents from the rear cargo area.
- 2) Place the safe inside the rear cargo area. **A1**
- 3) Notice four threaded fittings, two in the front and the back. Hand thread the self-drilling screws into each fitting.
- 4) Tighten all 3 screws using a six-point 10mm socket to 7Nm [61.95 in-lb]. **A2**
- 5) The installation is now complete.

**NOTE: This safe is a permanent installation, however in the event the safe is ever removed please insert the black plugs provided with the kit into each of the four exposed holes.**



# Combination Lock Reset Guides:

## Installation Steps:

**IMPORTANT:** Make sure to set your combination **BEFORE** installing your safe

Before setting your combination, ensure safe door remains **OPEN** to prevent accidental lockout



⇒ [4 Digit Lock User Guide](#)



⇒ [3 Digit Lock User Guide](#)



⇒ [Elite 4-Digit Lock  
User Guide](#)